

Switch Cap

SWEETA


SC4 series with inner size 3.3x3.3mm for pushbutton switch



SC401
Ø9.8 , H:10.8



SC402
Ø5.4 , H:12.8



SC403
Ø9.0 , H:10.2



SC404
□5.3x5.3 , H:9.2



SC405
5.6x11 , H:10



SC406
5.6x9.8 , H:11.3



SC407
5.6x12.2 , H:11.2



SC408
7.5x15 , H:11



SC409
6.3x17.3 , H:12.1



SC410
7.7x15.1 , H: 15



SC411
7x12.2 , H:11



SC412
19.7x10.1 , H:11.5



SC414
Ø11.8 , H:12.4




SC415
Ø14 , H:14




SC417
Ø6.3 , H: 7.3




SC418
Ø7.5 , H: 4.5



SC419
5.7x7.3 , H:12.4



SC420
4.8x6.3 , H: 24



SC421
4.8x7.4 , H:30




SC422
□5.3x5.3 , H:14.7



SC423
Ø7.3 , H:8.9



SC424
Ø7.5 , H:5.6



SC425
4.8x7.4 , H:30



SC426
Ø12 , H: 6



SC427
Ø8.4 , H:8.7